

The Coldbuster foot warmer mat is a cost effective way to keep your feet warm at home or in the office. The 90W heater uses a fraction of the 1000 - 2000W energy used by regular radiant or fan electric heater alternatives.

The foot warmer mat simply plugs into a power point and heats up immediately. The hard wearing carpeted surface and non-slip rubber backing ensure a robust appliance. The heater can be turned on and off with the convenient foot switch.

Description

Coldbuster has taken the advantages of floor heating and packaged it into a portable, energy efficient, personal foot warmer mat.

The Coldbuster foot warmer mat is 400 x 600mm with a soft carpet finish, durable overlocking around the edges and a non-slip rubber base.

The 1.8m long power lead plugs directly into a power point with an in-line molded plug. A convenient foot switch with LED on/off indicator ensures ease of use.

The Coldbuster foot mat has 2 built-in overheat protectors to comply with CE directives.



Specification

Model No:	V-13
Length:	600mm
Width:	400mm
Cord:	1.8m power lead
Switch:	LED foot switch
Colour:	Grey
Temp:	45 - 55°C approx.
Wattage:	90W
Amperage:	0.65A
Cost per hr:	3cents approx. (at 20c per Kwh)

Built in over-heating protection



Energy Efficient



12 Month Warranty



European Conformity



Electromagnetic Immunity

Instructions for Use

Simply plug the heating carpet into a standard 240 volt outlet.

Turn the mat on and off using the foot switch.

When turned on the LED indicator will be red.

When foot warmer is not being used for a long period of time, be sure to unplug it from the power socket in order to prolong shelf

Product Cleaning

- Do not wash the heating mat with water
- Do not dry clean
- If necessary to clean the carpeting surface, use dry cleaning foam. Spread it evenly over the surface brushing it lengthwise.
- If any part of the product is at all wet, it must be completely dried before being plugged in again.

Safety Instructions

- Do not place insulating objects (e.g. bean bags) on top of the heater as they may cause over heating.
- Do not allow infants, elderly or people who are intellectually disabled sit on the mat for prolonged periods as they may be unaware of overheating.
- Do not use the mat for warming animals as they may chew or bite the mat.
- Do not use the mat if the overlocking is worn or the carpet or rubber surfaces delaminate.
- Do not fold
- Do not stick any pins, needles or any other metal objects into the product
- Do not immerse in water. If the heater or foot button is wet, allow the mat to dry before re-use.
- Do not use to warm up animals

No claims for consequential damage, inconvenience or other losses resulting from the use or misuse of this mat will be entertained.

The Coldbuster foot warmer mat carries a 1 year Guarantee against manufacturing defects from the date of purchase, conditional upon its intended use as described above.